

HAUL MORE.

Get more usable length from your pickup's cargo bed with a BED X-TENDER™. Made of super strong aircraft-grade aluminum, this proven design is extremely lightweight, yet tough enough to use as a bench. Whatever you load in your truck, keep it secure with the original truck bed extender – the Bed X-Tender™ designed, engineered and built by AMP Research.



EASY TO USE: Lower the tailgate and flip the Bed X-Tender out to gain an extra two feet of enclosed bed length – perfect for motorcycles, ATVs, bicycles, garden supplies and equipment or any long cargo. Create a smaller enclosed area for shopping bags, small tools or camping gear by flipping the Bed X-Tender forward and closing the tailgate. Easy to install or remove and strong enough to use as a bench.



INSTANTLY ADDS AN EXTRA TWO FEET OF USABLE LENGTH TO YOUR TRUCK'S CARGO BED.

AVAILABLE IN A DURABLE BLACK OR SILVER POWDER COAT FINISH.

LIGHTWEIGHT, SUPER STRONG ALUMINUM ALLOY TUBES.

RUGGED GLASS-REINFORCED NYLON COMPOSITE UPRIGHTS.

3-YEAR LIMITED WARRANTY.

MADE IN USA.

NEW!



AMP RESEARCH MOTOXTENDER™ – Designed specifically for smaller trucks, this unique slant-back design provides extra length needed to secure full-size motorcycles or ATVs in popular compact, short bed pickups.



This product is Nationally Distributed by Bestop. To find a dealer in your area, please call toll-free 1-800-845-3567 or visit www.bestop.com



NEW!

BED X-TENDER™ APPLICATIONS							 EXTRA KIT REQUIRED FOR INSTALLATION
TRUCK BED SIZE / STYLE ▶	LARGE BED	FLAIRSIDE BED	LARGE DEEP BED	SMALL BED	SMALL BED MOTOXTENDER		
PART NUMBER - Silver Finish ▶	74500-00	74502-00	74503-00	74501-00	74509-00		
PART NUMBER - Black Finish ▶	74500-01	74502-01	74503-01	74501-01	74509-01		
CHEVROLET / GMC							
Colorado / Canyon - Short bed - 2004 – 2009	<i>(Requires extra mounting kit)</i>						74600-01
Silverado / Sierra - Stepside bed - 2007 – 2009	<i>(Requires extra mounting kit)</i>						74606-01
Silverado / Sierra - Standard bed - 2007 – 2009	<i>(Requires extra mounting kit)</i>						74606-01
Silverado / Sierra - Stepside bed - up to 2007 Classic		●			●		
Silverado / Sierra - Standard bed - up to 2007 Classic	●						
S10 - Stepside bed - 1996 – 2004	<i>(Requires extra mounting kit)</i>						74601-01
S10 - Standard bed - 1996 – 2004	<i>(Requires extra mounting kit)</i>						74601-01
C/K Pickup - Stepside bed - 1988 – 2000		●					
C/K Pickup - Standard bed - 1988 – 2000	●						
DODGE							
Dakota - Standard bed - 1987 – 2009		●			●		
Ram - Stepside bed - all model years	●						
Ram - Standard bed - 1982 – 2009	●						
FORD							
F-150 - Flairside bed - all model years		●					
F-150 - Standard bed - 2004 – 2009	<i>(Optional no-drill bracket)</i>						74602-01
Lincoln Mark LT - Standard bed - 2006 – 2009	<i>(Optional no-drill bracket)</i>						74602-01
F-150 - Standard bed - up to 2004 Heritage Edition	●						
F-250 / F-350 Super Duty - Standard bed - 2008 – 2009	<i>(Optional no-drill bracket)</i>						74602-01
F-250 / F-350 Super Duty - Standard bed - up to 2007	●						
Ranger - Flairside bed - 1982 – 2009		●					
Ranger - Standard bed - 1982 – 2009				●	●		
Explorer Sport Trac - 2001 – 2009		●					
ISUZU							
Hombre - Standard bed - 2006 – 2008				●	●		
MAZDA							
B-Series - Standard bed - 1994 – 2009	<i>(Requires extra mounting kit)</i>						74601-01
MITSUBISHI							
Raider - Standard bed - 2006 – 2008				●	●		
NISSAN							
Frontier - Standard bed - 1998 – 2009				●	●		
Titan - Standard bed - 2004 – 2009	●						
Pickup - Standard bed - all earlier models	<i>(Requires extra mounting kit)</i>						74601-01
TOYOTA							
Tundra - 2007 – 2009	<i>(Requires extra latch kit)</i>						74603-01
Tundra - 2000 – 2006	<i>(Requires extra latch kit)</i>						74603-01
Tundra D-Cab - 2000 – 2006	<i>(Requires extra latch kit)</i>						74603-01
Tacoma - 2005 – 2009	<i>(Requires extra latch kit)</i>						74603-01
Tacoma - 1995 – 2004				●	●		
T-100 Pickup - Standard bed - 1993 – 1998	<i>(Requires extra latch kit)</i>						74603-01
Pickup - Stepside bed - 1984 – 1994	<i>(Requires extra mounting kit)</i>						74601-01
Pickup - Standard bed 1984 – 1994	<i>(Requires extra mounting kit)</i>						74601-01
BED X-TENDER EXTRAS							
Quick Latch Mounting Bracket Kit	<i>(Optional kit compatible with all models)</i>						74605-01
Standard Mounting Bracket Kit	<i>(Standard with Bed X-Tender)</i>						74604-01